

STT850 and STT750 SmartLine Temperature Transmitter HART[®] Communications Options Safety Manual

34-TT-25-05

Revision 4

September 2017

Copyrights, Notices and Trademarks

© Copyright 2017 by Honeywell, Inc.

Revision 4, September 2017

While the information in this document is presented in good faith and believed to be accurate, Honeywell disclaims any implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in the written agreement with and for its customers. In no event is Honeywell liable to anyone for any indirect, special, or consequential damages. The information and specifications in this document are subject to change without notice.

Honeywell, TDC 3000, SFC, SmartLine, PlantScape, Experion PKS, and TotalPlant are registered trademarks of Honeywell International Inc. Other brand or product names are trademarks of their respective owners.

Honeywell Process Solutions
1250 W Sam Houston Pkwy S
Houston, TX 77042

About This Document

Release Information

STT850 and STT750 SmartLine Transmitter HART® Communications Options Safety Manual,
34-TT-25-05.

Revision	Date of Change	Details of Change
1	March 2014	1 st Release (STT850 only)
2	August 2015	STT750 Temperature Transmitter added.
3	March 2016	Digital Output for STT850
4	September 2017	Failure rates info added

References

The following list identifies publications that may contain information relevant to the information in this document.

STT850

- STT850 SmartLine Temperature Transmitter Specifications, 34-TT-03-14
- STT850 SmartLine Temperature Transmitter Quick Start Installation Guide,
34-TT-25-04
- ST T 850 SmartLine Temperature Transmitter User Manual, Document # 34-TT-25-03
- STT850 SmartLine Temperature Transmitter HART/DE Option User's Manual,
34-TT-25-06

STT750

- STT750 SmartLine Temperature Transmitter Specification, 34-TT-03-16
- STT750 SmartLine Temperature Transmitter Quick Start Installation Guide,
34-TT-25-14
- ST T 750 SmartLine Temperature Transmitter User Manual, Document # 34-TT-25-13
- STT750 SmartLine Temperature Transmitter HART Option User's Manual,
34-TT-25-16

Patent Notice

The Honeywell STT850 SmartLine Temperature Transmitter family is covered by one or more of the following U. S. Patents: 5,485,753; 5,811,690; 6,041,659; 6,055,633; 7,786,878; 8,073,098; and other patents pending.

Support and Contact Information

For Europe, Asia Pacific, North and South America contact details, refer to the back page of this manual or the appropriate Honeywell Solution Support web site:

Honeywell Corporate www.honeywellprocess.com
Honeywell Process Solutions www.honeywellprocess.com/temperature-transmitters/
Training Classes <http://www.honeywellprocess.com/en-US/training>

Telephone and Email Contacts

Area	Organization	Phone Number
United States and Canada	Honeywell Inc.	1-800-343-0228 Customer Service 1-800-423-9883 Global Technical Support
Global Email Support	Honeywell Process Solutions	ask-ssc@honeywell.com

Terms and Abbreviations

1oo1	One out of one
Basic Safety	The equipment must be designed and manufactured such that it protects against risk of damage to persons by electrical shock and other hazards and against resulting fire and explosion. The protection must be effective under all conditions of the nominal operation and under single fault condition
DU	Dangerous Undetected failures
FMEDA	Failure Modes, Effects and Diagnostic Analysis
Functional Safety	The ability of a system to carry out the actions necessary to achieve or to maintain a defined safe state for the equipment / machinery / plant / apparatus under control of the system
GTS	Global Technical Support Center
HART®	Highway Addressable Remote Transducer
HFT	Hardware Fault Tolerance
Low demand mode	Mode, where the frequency of demands for operation made on a safety-related system is no greater than one per year and no greater than twice the proof test frequency.
PFD_{AVG}	Average Probability of Failure on Demand
Safety	Freedom from unacceptable risk of harm
Safety Assessment	The investigation to arrive at a judgment - based on evidence - of the safety achieved by safety-related systems. Further definitions of terms used for safety techniques and measures and the description of safety related systems are given in IEC 61508-4.
SFF	Safe Failure Fraction, the fraction of the overall failure rate of a device that results in either a safe fault or a diagnosed unsafe fault.
SIF	Safety Instrumented Function, a set of equipment intended to reduce the risk due to a specific hazard (a safety loop).
SIL	Safety Integrity Level, discrete level (one out of a possible four) for specifying the safety integrity requirements of the safety functions to be allocated to the E/E/PE safety-related systems where Safety Integrity Level 4 has the highest level of safety integrity and Safety Integrity Level 1 has the lowest.
SIS	Safety Instrumented System – Implementation of one or more Safety Instrumented Functions. A SIS is composed of any combination of sensor(s), logic solver(s), and final element(s).

Contents

Terms and Abbreviations	v
1 — Requirements	1
Requirements for use of the manual	1
2 — Safety Function	2
Primary Safety Functions	2
Secondary Safety Functions	2
Systematic Integrity: SIL 3 Capable	2
3 — Designing with the HONEYWELL STT850 & STT750	3
Diagnostic Response Time	3
Logic Solver Inputs	3
Reliability data and lifetime limit	3
Environmental limits	4
Application limits	4
4 — Installation with the HONEYWELL STT850 & STT750	5
Parameter settings	5
5 — Operation and Maintenance with the HONEYWELL STT850 & STT750	6
Proof test	6
Calibration procedure	7
Remote Parameter Configuration Verification	8
Repair and replacement	9
Firmware update	9

This page has been intentionally left blank

1 — Requirements

Requirements for use of the manual

This section is intended for user's who have our STT850 & STT750 SmartLine Temperature Transmitter with the HART® Communication option with SIL. Any other option is not specifically covered by this manual.

IEC 61508 Ed. 2.0 compliant hardware/software revisions for the STT850 & STT750 SmartLine Temperature Transmitter can be found in the Exida and TÜV Certification Reports. In addition, the most recent release information can be found in the following document:

<https://www.honeywellprocess.com/library/support/Public/Downloads/SmartLineHARTTemperatureFirmwareRevisions.zip>

This document can be downloaded using the following link:

[SmartLineHARTTemperatureFirmwareRevisions.zip](https://www.honeywellprocess.com/library/support/Public/Downloads/SmartLineHARTTemperatureFirmwareRevisions.zip)

2 — Safety Function

Primary Safety Functions

The HONEYWELL STT850 & STT750 measures the temperature (or mV, Volts or ohms) of a process and reports the measurement within a safety accuracy of 2%.

Secondary Safety Functions

The HONEYWELL STT850 & STT750 performs automatic diagnostics to detect internal failures and reports these failures via out of band signals on the 4 – 20 mA output.

The transmitter needs a power cycle in order to recover from this condition.

If the Digital Output (STT850 only) is configured for "Critical Diagnostic" then it will turn on when the automatic diagnostics detect an internal failure.

Systematic Integrity: SIL 3 Capable

SIL 3 Capability:

The product has met manufacturer design process requirements of Safety Integrity Level (SIL) 3. These are intended to achieve sufficient integrity against systematic errors of design by the manufacturer. A Safety Instrumented Function (SIF) designed with this product must not be used at a SIL level higher than the statement without “prior use” justification by end user or diverse technology redundancy in the design. This is a Type B device.

3 — Designing with the HONEYWELL STT850 & STT750

Diagnostic Response Time

The HONEYWELL STT850 & STT750 will report an internal failure within 12 minutes of fault occurrence (worst case).

The transmitter will be put to burnout output if

1. PV is not updated in 5 seconds
2. 4-20mA Output Current is not as expected in 2.5 minutes
3. Electronics fault is found in 12 minutes (worst case).
4. If the Digital Output (STT850 only) is configured for "Critical Diagnostic" then it will turn on at these same times

The transmitter needs to be power cycled in order to recover from the burnout condition.

Logic Solver Inputs

The logic solver must be configured so that the engineering range in the transmitter matches the expected range of the logic solver.

To take advantage of the internal diagnostics in the STT850 & STT750, the logic solver must be configured to annunciate an out of band current reading (greater than 20.8 mA. or less than 3.8 mA.) in standard configuration or (greater than 20.5 mA. or less than 3.8 mA.) with Namur configuration as a diagnostic fault. The logic solver configuration must consider the slew time of the current signal and ensure that filtering is used to prevent a false diagnostic failure annunciation.

If the Digital Output (STT850 only) is used for a Logic Solver application, then the transmitter must be configured to use only the High Burnout mode as the Digital Output is shut off when the transmitter is in Low Burnout."

Reliability data and lifetime limit

A detailed Failure Mode, Effects, and Diagnostics Analysis (FMEDA) report is available from HONEYWELL. This report details all failure rates and failure modes, common cause factors for applications with redundant devices and the expected lifetime of the HONEYWELL STT850 & STT750 AND STT750.

The HONEYWELL STT850 & STT750 is intended for low demand mode applications up to SIL 2 for use in a simplex (1oo1) configuration, depending on the PFD_{AVG} calculation of the entire Safety Instrumented Function. STT850 & STT750 is classified as type B device according to IEC61508, having a hardware fault tolerance of 0.

The development process of the HONEYWELL STT850 & STT750 is certified up to SIL3, allowing redundant use of the transmitter up to this Safety Integrity Level, depending the PFD_{AVG} calculation of the entire Safety Instrumented Function.

When using the HONEYWELL STT850 & STT750 in a redundant configuration, a common cause factor should be included in reliability calculations. For reliability calculation details, useful lifetime and SFF, see the FMEDA report.

The reliability data listed the FMEDA report is only valid for the useful life time of the HONEYWELL STT850 & STT750. The failure rates of the HONEYWELL STT850 & STT750 may increase sometime after this period. Reliability calculations based on the data listed in the FMEDA report for mission times beyond the lifetime may yield results that are too optimistic, i.e. the calculated Safety Integrity Level will not be achieved.

Failure rates of the T/C, RTD, and E/U meter must be added and considered in the overall failure rate for the STT850 & STT750.

Environmental limits

The environmental limits of the HONEYWELL STT850 & STT750 are specified in the customer spec sheets as given in the STT850 & STT750 Specification 34-TT-03-14.

Application limits

The application limits of the HONEYWELL STT850 & STT750 are specified in the User Manual. If the transmitter is used outside of the application limits the reliability data provided becomes invalid.

4 — Installation with the HONEYWELL STT850 & STT750

The person with knowledge of safety operations will be required to do the installation and operation. No special installation is required in addition to the standard installation practices outlined in the STT850 & STT750 Smart Transmitter User Manual. However please note that when the device is in safety operation the optional write protect must be set in hardware and software both so that the device is write protected and HART® devices must be disconnected. This can be done using the write protect jumper. See STT850 & STT750 Smart Transmitter User Manuals for details concerning the write protect jumper (STT850 – 34-TT-25-03, STT750 – 34-TT-25-13). Also note that when the device is in safety operation the Latching and Break Detect parameters must be enabled.

If the Digital Output (STT850 only) function is being used in a Safety Application then it too should be set for Latching. Also, as the Digital Output is disabled when the transmitter is in the Low-burnout mode, then when using a Digital Output in a Safety Application the transmitter should only be configured to use High-burnout mode. See STT850 & STT750 Smart Transmitter User Manuals for details concerning these parameters

The software write protect is also available in the device with a password to disable the software write protect. The default password is “0000”. It can be enabled / disabled through HART host. IEC 61508 Ed. 2.0 compliant hardware/software revisions for the STT850 & STT750 can be found in the Exida and TÜV Certification Reports. In addition, the most recent release information can be found in the following document:

<https://www.honeywellprocess.com/library/support/Public/Downloads/SmartLineHARTTemperatureFirmwareRevisions.zip>

Parameter settings

The following parameters need to be set in order to maintain the designed safety integrity:

mA Fault action (Upscale/Downscale)	The transmitter is shipped with a default failsafe direction of upscale (21.5 mA.). This is acceptable for all high trip applications. For low trip applications, the fail-safe direction is downscale (3.5 mA.). A jumper on the transmitter may be changed to accomplish this action, see the User Manual.
Engineering Range	All engineering range parameters must be entered to match the trip points in the safety logic solver. These parameters must be verified during the installation and commissioning to ensure that the correct parameters are set in the transmitter. Engineering range parameters can be verified by reading these parameters from the local display or by checking actual calibration of the transmitter.

5 — Operation and Maintenance with the HONEYWELL STT850 & STT750

Proof test

The objective of proof testing is to detect failures within the HONEYWELL STT850 & STT750 that are not detected by the automatic diagnostics of the transmitter. Of main concern are undetected failures that prevent the safety instrumented function from performing its intended function.

The frequency of proof testing, or the proof test interval, is to be determined in reliability calculations for the safety instrumented functions for which the HONEYWELL STT850 & STT750 is applied. The Exida exSILentia® tool is recommended for these calculations. The proof tests must be performed more frequently than, or as frequently as specified in the calculation in order to maintain the required safety integrity of the safety instrumented function. The following proof test is recommended. It consists of a simple HART® driven min to max output test. The results of the proof test need to be documented and this documentation should be part of a plant safety management system. Any failures that are detected and that compromise functional safety should be reported to the Global Technical Support Center (GTS).

See STT850 & STT750 Smart Transmitter User Manual for more details (STT850 – 34-TT-25-03, STT750 – 34-TT-25-13).

<u>Step</u>	<u>Action</u>
1	Bypass the safety PLC or take other appropriate action to avoid a false trip, following Management of Change procedures.
2	Send a HART® command to the transmitter to go to the high alarm current output and verify that the analog current reaches that value. This procedure tests for compliance voltage problems such as a low loop power supply voltage or increased wiring resistance. This also tests for other possible failures.
3	Send a HART® command to the transmitter to go to the low alarm current output and verify that the analog current reaches that value. This test checks for possible quiescent current related failures.
4	Use the HART® communicator to view detailed critical and non-critical device status to ensure no alarms or warnings are present in the transmitter.
5	Verify all safety critical configuration parameters.
6	The WP jumper state should be checked to see if it is in WP mode first, and then changed to Enable to ensure a change is detected by device while configuring, and then moved back to WP after the configuration is complete. Then it should be verified again.
7	Calibrate the device as per calibration procedure given below.
8	Restore the loop to full operation.
9	Power cycle or cold reset to clear soft errors in memory (RAM).
10	Remove the bypass from the safety PLC or otherwise restore normal operation.
11	If Digital Output (DO) is present, change the monitored input such that the DO turns on and off. Monitor the output to confirm that the DO works as expected.

This test will detect approximately 30% of possible DU failures in the transmitter (Proof Test Coverage). An alternative proof test consisting of proof test 1 with actual two point temperature calibration plus verification of the temperature measurement will detect approximately 48% of possible DU failures.

The person(s) performing the proof test of the HONEYWELL STT850 & STT750 should be trained in SIS operations, including transmitter maintenance and company Management of Change procedures. Tools required are: handheld communicator.

Calibration procedure

The transmitter should be taken out of service. The source for the input Temperature must be very precise, and certified for correct operation.

Step	Action
1	Connect the HART host and establish the communications.
2	Go to Online > Device Setup > Calibration > Calibration Methods menu.
3	Go to "D/A Trim"
4	Message "Warn loop should be removed from automatic control" will appear. Press "Ok".
5	Message "Connect reference meter" will appear. Connect the reference meter and press "Ok".
6	Message "Setting fld device output to 4mA" will appear. Press "Ok". Message "Enter meter value (4,000mA)" will appear with a textbox to enter actual value observed on meter. Enter the actual value and press "Enter".
7	Message "Fld dev output 4,000mA equal to reference meter?" will appear with Yes/No selection. Select "Yes" and "Enter".
8	Message "Setting field device output to 20mA" will appear. Press "Ok".
9	Message "Fld dev output 20,000mA equal to reference meter?" will appear with Yes/No selection. Select "Yes" and "Enter".
10	Message "Returning fld dev to original output" will appear. Press "Ok".
11	Now Double click "URV Correct" method
12	Message "WARN-Loop should be removed from automatic control" will appear. Press "Ok".
13	Message "Please enter calibration date" will appear. Enter the current date and press "Ok".
14	Message "Please enter current calibration time in 24 hr clock format (hour field)" will appear. Enter the current time hour and press "Ok".
15	Message "please enter current calibration time (min field)" will appear. Enter the current time minutes and press "Ok".
16	Message "Apply URV Temperature" will appear.
17	Adjust the PV input to the required URV value. Press "Ok".
18	Message "Press ok when Temperature is stable" will appear. Press "Ok"
19	The correct URV operation will happen .
20	Message "Loop may be returned to automatic control" will appear. Press "Ok".
21	Follow the same procedure for "Correct LRV" (replace URV in above procedure by LRV) and "Correct LRV" operation will get executed.

Repair and replacement

Any failures that are detected and that compromise functional safety should be reported to the Global Technical Support Center (GTS).

When replacing the HONEYWELL STT850 & STT750 the procedures in the installation manual should be followed.

Firmware update

The user will not be required to perform any firmware updates. If the user has selected the firmware upgrade option, it can be done by Honeywell service representative.

This page has been intentionally left blank

Sales and Service

For application assistance, current specifications, pricing, or name of the nearest Authorized Distributor, contact one of the offices below.

ASIA PACIFIC

Honeywell Process Solutions,
(TAC) hfs-tac-support@honeywell.com

Australia

Honeywell Limited
Phone: +(61) 7-3846 1255
FAX: +(61) 7-3840 6481
Toll Free 1300-36-39-36
Toll Free Fax:
1300-36-04-70

China – PRC - Shanghai

Honeywell China Inc.
Phone: (86-21) 5257-4568
Fax: (86-21) 6237-2826

Singapore

Honeywell Pte Ltd.
Phone: +(65) 6580 3278
Fax: +(65) 6445-3033

South Korea

Honeywell Korea Co Ltd
Phone: +(822) 799 6114
Fax: +(822) 792 9015

EMEA

Honeywell Process Solutions,
Phone: + 80012026455 or
+44 (0)1344 656000

Email: (Sales)

FP-Sales-Apps@Honeywell.com

or

(TAC)

hfs-tac-support@honeywell.com

AMERICAS

Honeywell Process Solutions,
Phone: (TAC) 1-800-423-9883 or
215/641-3610
(Sales) 1-800-343-0228

Email: (Sales)

FP-Sales-Apps@Honeywell.com

or

(TAC)

hfs-tac-support@honeywell.com



Honeywell

AUTHORIZED DISTRIBUTOR

De Gidts & Feldman BV

The Netherlands

w w w . d g f g . n l



De Gidts & Feldman

INSTRUMENTATION & FILTRATION

For more information

To learn more about SmartLine Transmitters,
visit www.honeywellprocess.com
Or contact your Honeywell Account Manager

Process Solutions

Honeywell
1250 W Sam Houston Pkwy S
Houston, TX 77042

Honeywell Control Systems Ltd
Honeywell House, Skimped Hill Lane
Bracknell, England, RG12 1EB

Shanghai City Centre, 100 Jungi Road
Shanghai, China 20061

www.honeywellprocess.com

Honeywell

34-ST-25-05, Rev.4
September 2017

©2017 Honeywell International Inc.
